


To attach the net:

Spread out the net and find the red tabs. Red tabs indicate the corners. Start with one corner and attach bungee cord (see figure 3). Follow by attaching remaining three corners. Start at top of the frame and attach three bungee cords across, spreading them evenly. Repeat on bottom, then the side poles. Repeat until all but 8 bungees cords remain.




(Figure 3)




WARNING:

Use extreme caution when assembling the net to the frame. The bungees will be under extreme tension and must be attached carefully. Adult assembly is strongly recommended.

- Attach the Strike Zone Ribbon by weaving through the net and connecting the Velcro at the end (see figure 4)
- Attach the Target: On the opposite side from the net, attach the Target to the frame with the remaining 8 bungees, 4 on the top, and 4 on the bottom. Snap on the ball collection bag to the bottom of the target.
- Use the Ground Stakes for extra stability when needed.



(Figure 4)



PITCH RETURN ADJUSTMENT

- Twist the height adjusters to tighten and loosen. Measurement lines have been provided on the back of tubes 9 & 10 so the pitch return can be adjusted evenly on both sides.



SWITCH HITTER TARGET

- The Target has a movable middle flap that can be adjusted to give a right-handed or left-handed batter image. Just snap the corners of the middle flap into place on either the right or left side of the main target area.



**MLB® 2-IN-1 SWITCH-HITTER™
PITCH TARGET AND RETURN TRAINER**

ASSEMBLY INSTRUCTIONS

ITEM #19069




RETURN TRAINER

PITCH TARGET



Franklin Sports Inc.
Stoughton, MA 02072
Made in China

For Replacement Parts Call:
1-781-341-5178 or 1-800-225-8649
OR visit www.franklinsports.com




Parts List:

PART	AMOUNT	DESCRIPTION	REPLACEMENT PART#
1	1	Top Corner Tube	19069-R1
2	1	Top Corner Tube	19069-R2
3	2	Top Middle Tubes	19069-R3
4	1	Bottom Middle Tube	19069-R4
5	1	Bottom Middle Tube	19069-R5
6	1	Bottom Corner Tube	19069-R6
7	1	Bottom Corner Tube	19069-R7
8	2	Back Middle Tubes	19069-R8
9	1	Back Corner Tube	19069-R9
10	1	Back Corner Tube	19069-R10
11	1	Hinge	19069-R11
12	1	Hinge	19069-R12
13	2	Height Adjusters	19069-R13
14	2	Bolts with Wing Nuts	19069-R14
15	1	Net	19069-R15
16	1	Strike Zone Ribbon	19069-R16
17	32	Bungees	19069-R17
18	4	Ground Stakes	19069-R18
19	1	Target w/Batter Graphic	19069-R19
20	1	Ball Collection Bag	19069-R20

Assembly:

Please remove all components from the package and confirm that all parts are included. Please reference the frame assembly diagram below (see Figure 1):

- Attach all of the tubes together to assemble the frame as pictured in the assembly drawing.



(Figure 1)

(Figure 2)