




# RYAN'S BACKYARD FOOT GOLF




ITEM NUMBER: **89192**



**WARNING:**  
CHOKING HAZARD--Small parts.  
Not for children under 3 yrs.


NOTE: PRINT FRONT TO BACK





- PARTS**
- 1  x1
  - 2  x1
  - 3  x1

**NOTE**

Place the targets on the ground in their desired locations.



- PARTS**
- 4  x1
  - 5  x1

**NOTE**

Inflate your Soccer Ball (4) using the Inflation Pump with Needle (5) that's included.

To find the needle in the pump, simply open the top cap as shown, take the needle out of this compartment (Figure 1), and screw into the bottom of the pump (Figure 2).

## YOU ARE NOW READY TO PLAY!

### GAME RULES:

Mark your "starting" location and begin by rolling the dice.

Round 1: Player 1 begins by kicking the soccer ball towards the target that was rolled on the dice! Count how many shots it takes to sink the hole! Once finished, Player 2 gets a turn to go after the same character target from the same "starting" location. Continue until all players have played out the first hole.

Round 2: Player 2 gets to role the dice to determine where they're shooting!

Continue playing for 10 rounds and make sure to keep track of your score after each round. The lowest score after 10 rounds wins!

Made In China  
Franklin Sports Inc.  
Stoughton, MA 02072  
TM & © REMKA



For replacement parts:  
Visit: [www.franklinsports.com/89192](http://www.franklinsports.com/89192)  
Email: [parts@franklinsports.com](mailto:parts@franklinsports.com)  
Call: 1-800-225-8649

# Franklin®

## CUSTOMER SERVICE COMMITMENT

Thank you for purchasing this product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

[parts@franklinsports.com](mailto:parts@franklinsports.com)

or

Visit our website at: [www.franklinsports.com/89192](http://www.franklinsports.com/89192)

If possible, please include product part number and parts description so we can best assist you.








## WE'RE HERE FOR YOU!

**PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.**

**WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.**

Thank you for your continued support, and welcome to the #FranklinFamily!



## PARTS LIST

1  Red Target Pieces QTY x6	2  Blue Target Pieces QTY x6	3  Green Target Pieces QTY x6	4  Soccer Ball QTY x1
5  Inflation Pump and Needle QTY x1	6  Hole Flags QTY x3	7  Dice QTY x1	

## ASSEMBLY INSTRUCTIONS



### GENERAL NOTE

Remove the product from the box and make sure all parts from the parts list are included. Find a clean, level place to begin the assembly of your RYAN'S WORLD FOOT GOLF.



NOTE

Start with the **Red Target Pieces (#1)**. Slide and lock each target piece in place as shown in the illustration. Continue sliding and locking each piece in place until the full circle target is assembled. Repeat this process for each color.



NOTE

Each target has 1 piece containing 2 holes for the flags. Take each **Flag (#6)** and insert into the holes of each target as shown. If playing outdoors, these can be pushed through the target and into the ground to act as ground stakes so the targets don't move around.